



ideale

TECHNICAL DATA SHEET

ULTRATHIN SANITARY NAPKINS

BELLA IDEALE



I. DESCRIPTION

Sanitary napkins Bella Ideale are made of two cellulose absorption webs (air-laid) from which one is containing superabsorbent powder. Superabsorbent has function of neutralization of bad smell. On such prepared core from outer side there is applied perforated laminate (Bella Ideale Staydrai) or embossed nonwoven (Bella Ideale Staysofti). Bottom, liquid impermeable layer of napkin consist of breathable polyethylene film, on which there is applied adhesive for positioning the napkin to the garment. Positioning adhesive is protected by silicone paper stripe. The napkin is glued by construction hot-melt type adhesive. Sanitary napkins Bella Ideale are individually wrap up in the silicone pouch film. Onto the sachet is put on closure tape. On the sanitary pads Bella Ideale Staydrai is applied parfum and printing, sanitary pads Bella Ideale Staysofti are without parfum but with printing.

II. RAW MATERIALS

	Regular/Normal		Night	
	Staydrai	Staysofti	Staydrai	Staysofti
airlaid with SAP	✓	✓	✓	✓
airlaid without SAP	✓	✓	✓	✓
perforated laminate	✓	-	✓	-
emossed nonwoven	-	✓	-	✓
ink	✓	✓	✓	✓
breathable PE film	✓	✓	✓	✓
adhesives (hot-melt)	✓	✓	✓	✓
release paper	✓	✓	✓	✓
parfum	✓	-	✓	-
silicone pouch film	✓	✓	✓	✓
closure tape	✓	✓	✓	✓

III. DIMENSIONS*

Size	Length [mm]	Absorbent core length [mm]	Width [mm]	Absorbent core width (front-crotch-back) [mm]
Regular/ Normal	235	217	155	75-65-75
Night	315	295	155	80-65-80

* tolerance dimension +/- 5mm

IV. PCHYSICO – CHEMICAL PROPERTIES

Size	Mass [g]	Water absorption [g] no less than	Adhesion [N] no less than	Optical brighteners
Regular/ Normal	5,4	120	1,5	inadmissible
Night	8,0	230	1,5	inadmissible

V. LOGISTICS

Size	Unit package [pcs]	Quantity of unit packages per carton case	Quantity of carton cases per palett	Transport packaging
Regular/ Normal	10	36	84	carton case
Night	7	24	108	carton case
Regular, Normal	20	24	63	carton case
Night	14	14	99	carton case

EURO pallet with product is wrapped around with a stretch film and protected (bottom and top) by protection film.

VI. STORAGE CONDITIONS

Sanitary napkins should be stored in dry and airy room, with temperature between 5°C and 35°C and humidity between 25%-75% in original packaging. Packaging must be unopened, wrapping with stretch film to avoid dust, impurities and unfamiliar odors.

VII. OTHERS

Validity :

Bella Ideale Regular/Normal Staydrai, Bella Ideale Night Staydrai: 36 months

Bella Ideale Regular/Normal Staysofti, Bella Ideale Night Staysofti: 60 months

Issued by:


Technolog
Bella Sp. z o.o

Accepted by:

Zastępca Dyrektora ds. Produkcji i Rozwoju Technologii Grupy TZMO

Z-CA DYREKTORA
PRODUKCJI I INNOWACJI


Tomasz Przybylski

Effective date: 18.04.2018